

# Connection Diagram for Input Signal Breakout Board to PMDX-126 J11 / J12

